

≓∧Z ⊑ LINE OPAL

STEP 2


Slide in aluminium joiner


A CAUTION - light fitting must be installed by a licensed electrician.

- Please ensure to read instructions correctly for the installation of the fitting provided. Failure to do so will result in a void of warranty and compromises the safety of luminaire.
- Radiant Lighting are not liable for warranties when luminaire is damaged by incorrect installation. The installation of the luminaires must be in accordance with the national safety regulations.


Please refer to Radiant Lighting's General Terms & Conditions for more information concerning the installation and warranty of our products.

Connection Instructions





Remove end cap and unscrew base to pull out the adapter.



Connect adapter

Please note: Maximum length is 9.6M before an extra power feed is required.

Category Ceiling / Suspension	CRI 90+
Power 15W / 30W / 45W / 60W	Material Aluminium
IP Rating 20	Warranty 5 Years



For warranty information please visit radiantlighting.com.au/warranty

STEP 3

Screw into place

STEP 5

Use allen key to screw fittings together